

Completed Assembly

Steps:

- 1) Connect base to post, using bolt.
- 2) Route cord from table top through post and base.
- 3) Connect table top to post, with fixed brackets, using black bolts.

SETUP INSTRUCTIONS

General Setup Instructions


- Read entire setup instruction manual prior to unpacking parts and pieces.
- The setup instructions are created specifically for this configuration.
- Setup instructions are laid out sequentially in steps, including exploded views with detailed explanation for assembly.




- For Cleaning Metal, Plex, & Laminate Parts: Use a MILD NON-ABRASIVE cleanser and soft cloth/paper towel to clean all surfaces.
- Keep exhibit components away from heat and prolonged sun exposure. Heat and UV exposure will warp and fade components.
- Retain all provided Packing Materials. All provided packing materials are for ease of repacking & component protection.

Disassembly


- For loss prevention, tighten all set screws and locks during disassembly.




Hex Tool - Essential for Assembly




Part Identification - Numbering




Spline Connection



Base Plate & Extrusion Connection



Extrusion & Lock Connection



Engaged Lock





DO NOT USE POWER TOOLS



LADDERS OR LIFTS MAY BE REQUIRED



ALL CONNECTIONS MUST BE TIGHTLY SECURED

Controlling the RGB LED lights

Static Mode:

- 1. Use the Color Ring key to select a color.
- 2. Saturation is controlled with W/R/G/B keys.
- 3. White mode is available by long-pressing 'ON' key.
- 4. Colors (not white) are dimmable with the Brightness key.


- Press "M" key to cycle through the following options:
- 1. White light fades in and out.
- 2. Several colors fade in and out
- 3. R,G,B three colors fade in and out.
- 4. R,G,B three colors flash.
- Six colors flash.
- 6. Random color flashes.
- 7. Red color fades in and flashes.
- 8. Green color fades in and flashes. 9. Blue color fades in and flashes.

To Pair a Remote with Multiple Units:

- 1. Power on the lights.
- 2. Press 'ON' key within 3 seconds.
- 3. Lights will blink when link is made.


To unpair: Long press 'ON' key within 3 seconds after switching on lights.

Remotes can be paired with one or more receivers. Different receivers can work synchronously even when started at different times (within 30 min).




- Remote Control: 1. Working voltage: DC12V/24V 1. Working voltage: 3V
- 2. Output: Max. 6A/Channel Total output Max. 10A 3. Max standby power: 0.5W

Top View of Each Level



Level 1 (Bottom level)



Setup Hardware

Level 2